

Birdhouse instructions by Sectomo Senior Carpenter Pekka Blomster

You need

- Untreated board, thickness around 19mm
- Saw & hammer
- Nails & screws
- Rope.

Place the bottom of the house inside the side walls to prevent water coming in. The roof and the door should slope about 5 degrees so that the water doesn't come in the house.

Attach a moving hatch to one side using either nails or pegs. Use a screw on the lower end of this side. It makes the house easier to clean.

Choose the location of the house based the bird you wish to live in the house. But remember that the bird chooses its house, not the other way around!

Use rope for attaching the house to the chosen tree. You can fix the rope to the house by using either a nail or a screw.

Remember to loosen the rope after each winter when you do the spring cleaning to the house, so that the rope doesn't get too tight and hurt the tree.

Dimensions for Bird X

A Height	370 mm
B Door Ø	50 mm
C	85 mm
D Bottom	130 mm

Please note we use "Bird X" as an average bird. This bird is around 20 cm long from the tip of the tail to the beak.

